

R 232 ONE TECHNICAL MANUAL

V2021.10

1.	GENERAL	.3
2.	TROUBLE SHOOTING	.5
3.	CARE AND MAINTENANCE	.7
4.	REPLACING DU BUSHINGS	.18
5.	REPLACING SPHERICAL BEARINGS	.23

1. GENERAL

1.1 VALIDITY

This manual describes the component specified on the front page and the footer. This manual is valid for the design of the product as of 15.10.21. Deviations are possible and all items are subject to technical changes.

1.2 SAFETY

The safety instructions are classified as follows:



DANGER

...indicates a hazardous situation that, if not avoided, will result in death or serious injury.



CAUTION

... indicates a hazard with a medium level of risk which, if not avoided, may result in minor or moderate injury.



NOTE

... indicates a potentially hazardous situation that may result in damage to property.

1.3 TARGET GROUP

This manual is intended for the user of the component and dealers. This manual offers the experienced user the possibility to carry out minor service work himself. If you have any doubts about your own abilities, you should definitely contact a specialist or a DT Swiss Service Center. Any warranty claims will lapse if work is not carried out properly.

1.4 LAYOUT

The cover page and the footing provide information about the type of product and manual as well as the version of the manual. The DT Swiss contact details can be found on the back. A list of all DT Swiss service centers can be found at www.dtswiss.com.

This manual is intended for being printed as an A5 booklet. Only print this manual if electronic usage is not possible.



1.5 GENERAL MAINTENANCE INFORMATION

Unless otherwise specified, moving parts, threads, O-rings and sealings must be greased before assembly.

CLEANING

For an optimal result of the maintenance works, every component that will be disassembled must be cleaned. Only use cleaners and degreasers which do not damage the components. Especially the cleaning of O-rings and sealings requires mild cleaners. Observe the instructions for use of the respective cleaner.

DT Swiss recommends the following cleaners:

- Motorex Rex
- Motorex Swissclean
- Motorex OPAL 2400, 3000 OPAL, OPAL 5000

Use soap water or similar mild cleaners for external cleaning.

TOOLS

To ensure a damage-free mounting and dismounting of the components, only use the tools which are mentioned in this manual. Special tools are indicated at the beginning of a chapter in the table "Required material".

The use of different tools is at the discretion of the user. If components are damaged by the usage of differing tools, the user is liable.

DT Swiss special tools are precision tools. Damage-free mounting and dismounting of the components can only be ensured if the tools are working properly and if the condition of the tools are perfect. Always keep the tools in their original packaging or adequate devices to prevent damage.

1.6 ENVIRONMENTAL PROTECTION

The statutory regulations shall apply. Whenever possible, avoid creating waste. Waste, especially carbon, lubricants, cleaners and any other fluids must be disposed in an environmentally compatible manner. Only print this manual if electronic usage is not possible.

1.7 EXCLUSION OF LIABILITY

The activities listed in this manual may only be carried out by persons with sufficient specialist knowledge. The user is liable for any damage or consequential damage caused by wrongly maintained or installed components. If you have doubts, please contact your region's DT Swiss pro level service center.

1.8 WARRANTY

Warranty conditions can be found at www.dtswiss.com.

2. TROUBLE SHOOTING

lssue	Reason	Solution
Air loss after long term storage or riding.	Normal effect. The shock can lose about 1-2 bar per month.	Inflate the shock and perform standard set up.
Air loss after short time.	Quadring, wiper or guide band of the air chamber is worn.	Change the sealings of the air chamber seal kit. See <u>"3. CARE</u> <u>AND MAINTENANCE" on page</u> <u>7</u> .
	Wrong grease used.	Disassemble and clean the inner surface of the air chamber and the oil chamber tab. Grease the inner surface of the air chamber, the oil chamber tab and the wiper using Slick Honey Bike Grease. See <u>"3. CARE AND MAINTENANCE"</u> on page 7.
	Air chamber is damaged.	Change the air chamber.
	The outer surface of the oil chamber is damaged / scratched.	Full service necessary. Contact a DT Swiss service center.
Tiny amounts of oil or grease on the outside.	Normal residue from installation or operation.	Clean the shock with a damp cloth after each ride.
Tiny amounts of oil on the rebound wheel or on the end cap.	None - normal residue from assembly.	Clean the area and check again after a while. If this area is oily again, a full service is necessary. Contact a DT Swiss service center.
Shock loses oil in the area of the rebound wheel.	O-ring of the lockout pin is damaged.	Full service necessary. Contact a DT Swiss service center.
Shock makes slight flowing sound (effect changes depending on the rebound adjustment).	Normal effect (damping effect of oil and bores).	
Shock makes "smacking" sound.	Air inside the oil chamber.	Full service necessary. Contact a DT Swiss service center.
The rebound does not work.	The rebound pin is stuck.	Full service necessary. Contact a DT Swiss service center.
The lockout does not work.	The remote cable is not adjusted correctly.	Adjust the remote cable via the knurled wheel.
	The sealing of the damping piston is worn or damaged.	Full service necessary. Contact a DT Swiss service center.
	The lockout cap does not close completely.	
	Only trunnion mount shocks: Dirt between lockout shaft and rebound wheel or between rebound wheel and end cap.	

lssue	Reason	Solution
The shock cannot be inflated (air escapes immediately when the	Valve or valve insert of the shock is damaged.	Change or retighten the valve inserts (max. 0.4 Nm).
pump is unscrewed).	Leakage.	Check in a water bath where the shock is leaking. Contact your dealer or a DT Swiss Service Center to solve the problem.
The pressure indicated on the pressure gauge rises rapidly while pumping.	Valve does not open.	Check the positioning of the pump on the shock or change the pump.
Shock has noticeable play at the spherical bearings / DU bushings.	Wrong mounting hardware, incorrect tightened screws or wear.	Check whether the correct mounting hardware was used or the screws are tightened correctly. If necessary, replace spherical bearing / DU bushings (see <u>"5.</u> <u>REPLACING spherical bearings"</u> on page 23. or <u>"4. Replacing DU</u> <u>bushings" on page 18</u>).
Loss of oil at the oil chamber (noticeable when the air chamber is removed).	Sealings are at their wear limits.	Full service necessary. Contact a DT Swiss service center.
Oil sprays out of the valve while deflating the air chamber.		
Noise while compressing the shock after about 10 mm of the stroke.	Normal sound of the air balance between the positive and the negative air chamber.	
Clacking noise when compressing.	Defective lockout cap.	Full service necessary. Contact a DT Swiss service center.
	IFP not in correct position.	Full service necessary. Contact a DT Swiss service center.
Shock squeaks while riding, when the shock gets hot.	Wiper seal is dry.	Small service necessary. See <u>"3. CARE AND MAINTENANCE"</u> on page 7.
Shock gets hot while riding.	The shock can get very hot on long downhills. This does not affect the performance of the shock.	

3. CARE AND MAINTENANCE

3.1 SAFETY

DANGER

DANGER TO LIFE DUE TO WRONG MAINTENANCE OF THE SHOCK!

Incorrect maintenance or assembly of the shock can lead to incorrect function!

- Maintenance and assembly may only be done by a skilled professional.
- In case of any doubt, contact a DT Swiss service center.
- Only use original spare parts.

3.2 CARE

The following care and cleaning instructions must be observed:

- Clean the shock with a damp cloth after each ride. Remove dirt accumulations in the area of the wiper seal.
- Never use aggressive cleaners that damage the wiper seal.
- Never use high pressure cleaners. Water and dirt can get into the shock and damage it!
- Remove all visible, dried dirt from the area of the wiper seal. This will prevent dirt from getting into the shock.
- It is not necessary to grease the shock in the area of the wiper seal.
- After cleaning, lubricate the sliding surface of the remote lever on the handlebar.

3.3 SERVICE INTERVALS

If service intervals are not respected, any warranty claims can be denied.

Task	Interval
Small Service	 intensive use: 40 operating hours normal use: 100 operating hours or as required
Full service carried out by a DT Swiss service center	Annually or after 200 operating hours
Check the shock for damage	Before and after each ride
Check the fastening is correct	Before each ride
Check the functionality	Before each ride
Clean with a soft sponge and a suitable cleaning agent, especially in the area around the wiper seal.	After each ride
Do not use high pressure cleaners or aggressive cleaning agents!	





Pos.	Description	Detail
1	support ring oil chamber tap	33 / 39 x 1.4 mm
2	quadring oil chamber tab	31.34 x 3.53 mm
3	0-ring end cap / air chamber	44.17 x 1.78 mm
4	quadring air chamber	26.64 x 2.62 mm
5	guide band	27.3 / 31.26 x 2.6 mm
6	wiper air chamber	26.15 / 36.2 x 5 mm

3.5 SMALL SERVICE

This chapter describes a small service. Further service works will be carried out by a DT Swiss service center.

A small service should be carried out in the following cases:

- The interval for a small service is expired (see table at the beginning of this chapter).
- Leakage that becomes apparent through repeated air loss. The shock must be inflated regularly.
- Unusual sounds (squeaking).
- Other defects or malfunctions.

Preparatory Steps	Link
Dismount the shock from the bike.	
Dismount the shock hardware.	
Clean the surface of the shock.	see "1.5 General Maintenance Information" on page 4

Required Material	Specification	Specification	
service kit air chamber	CWKR232X3019	CWKR232X30197S	
grease		Buzzy's Slick Honey	as required
	ASTICK	4.7 dl: 40341000AD02000001	
	HONEY Construction of the	or	
		20 ml: TZXXXXXNSLICKS	



NOTE

RISK OF DAMAGING THE SHOCK!

To avoid damages, always clamp the shock or parts of the shock into ground clamping jaws, aluminum clamping jaws or plastic clamping jaws.



RELEASING THE AIR

DANGER

SHOCK OIL MAY BE FATAL IF SWALLOWED AND ENTERS AIRWAYS!


Oil mist might escape through the valve while releasing the air from the air chamber.

- Always place a cloth on the valve while deflating.
- The valve must face down, away from your body while releasing the air.

RISK OF INJURY FROM PRESSURIZED COMPONENTS!

After the air has been released, there may still be pressure in the negative air chamber!

- If the air is released too quickly, the pressure of the positive and negative air chambers will not be balanced. The shock will fully compress and the pressure in the negative air chamber remains.
- If there is any doubt as to whether the pressure in the negative air chamber has been completely released, measure the shock length after the air has been released. When the negative air chamber is completely empty, the shock does not compress.
- DO NOT remove the air chamber until the positive and negative air chambers are completely deflated.
- 1. Unscrew the valve cap on the shock.
- 2. Position the shock so that the valve faces away from the body and face and place a cloth on the valve.
- 3. Slowly press the valve core with the back of the valve cap or better: Screw on the shock pump and slowly reduce the air pressure by pressing the release valve on the shock pump.
 - → The shock can compress up to the point at which the equalization of the positive and negative air chambers occurs.




4. If the shock fully compresses when air is released, reinflate the shock and release the air more slowly. OR manually pull the shock apart and compress it approximately 10 mm from fully extended position, allowing air to flow from the positive air chamber into the negative air chamber. Repeat the procedure a few times and deflate again.

After releasing the air, the shock must not be compressed! If in doubt, measure the length of the shock!

REMOVING THE AIR CHAMBER


1. Remove the SAG O-ring from the oil chamber.



RISK OF DAMAGING THE SHOCK!

To avoid damages, always clamp the shock or parts of the shock into ground clamping jaws, aluminum clamping jaws or plastic clamping jaws.


- 2. Ensure that the air has been released completely (see <u>on page 10</u>).
- 3. Clamp the shock into a vice vertically.
- Unscrew the air chamber by hand. If the air chamber can not be loosened by hand, unscrew the air chamber using a strap wrench.
- 5. Slide off the air chamber.
- Check if there is damping oil in the air chamber. If this is the case, the entire oil chamber cap assembly must be replaced as part of a full service.
- 7. Take the shock out of the vice.





CHANGING THE SUPPORT RINGS AND THE QUADRING


1. Remove both support rings.




2. Remove the quadring.

3. Clean the oil chamber tap See <u>"Cleaning" on</u> page 4.

4. Grease the new quadring and fit it onto the oil chamber tap.




- Fit two new support rings on the oil chamber tab The support rings must be fitted on both sides of the quadring.
- 6. Ensure that the quadring is not twisted or damaged.






CHECKING THE AIR CHAMBER FOR DAMAGES

- 1. Check the air chamber housing for
 - scratches on the inner surface
 - wear
 - cracks
- 2. Replace the air chamber housing if damaged.




REPLACING THE WIPER SEAL, QUADRING AND GUIDE BAND

- 1. Carefully remove the wiper seal from the air chamber using plastic forceps.
 - \rightarrow The air chamber must not be damaged!
 - \rightarrow Do not re-use the wiper seal!




 \rightarrow Do not reuse the guide band!






- 3. Remove the quadring from the air chamber by hand.
 - ightarrow Do not re-use the quad-ring!




- 4. Clean the air chamber housing with a clean, lint-free and dry cloth. There must be no lint and no residuals of grease after cleaning!
- 5. Slightly grease the new quad-ring and put it into the inner groove of the air chamber (see figure).
 - ightarrow Ensure that the quad-ring is not twisted.

6. Put a new guide band onto the web between both grooves of the air chamber (see figure).



- 7. Slightly grease the new wiper seal and put it into the outer groove of the air chamber (see figure).
 - → Ensure, the wiper seal lays evenly all around the groove.




DT SWISS

REPLACING THE O-RING BETWEEN END CAP AND AIR CHAMBER


Only shock with standard mount:

- 1. Remove the O-ring from the end cap.
- 2. Grease the new O-ring and install it on the end cap.



Only shock with trunnion mount:


- 1. Remove the O-ring from the air chamber.
- 2. Grease the new O-ring and install it on the air chamber.



GREASE THE INNER SURFACE OF THE AIR CHAMBER


 Lightly grease the inside surface of the air chamber, the guide band and the seat of the O-ring.

The wiper must be greased generously.




ASSEMBLING THE AIR CHAMBER

1. Lightly grease the quadring, the support rings and the oil chamber.



- 2. Clamp the shock into the vice.
- 3. Slide on the air chamber and tighten it by hand.
 - \rightarrow Make sure that the support rings on the oil chamber tab are not twisted.
 - \rightarrow Make sure the 0-ring is not pinched between the air chamber and the end cap.
 - \rightarrow If the air chamber cannot be pushed down by hand, mount the shock in the bike, compress it and screw on the air chamber at the same time.
- Take the shock out of the vice. 4

5. Put the SAG O-ring onto the oil chamber.



Closing steps.	Link
Dispose all waste in an environmentally compatible manner.	<u>"1.6 Environmental protection" on page 4</u>
Assemble the shock to your bicycle.	




4. REPLACING DU BUSHINGS

DT Swiss shocks use DU bushings or spherical bearings. These two types, as well as their hardware and tools, are not compatible with each other.

Preparatory Steps	Link
Dismount the shock from the bike.	
Clean the surface of the shock.	see <u>"Cleaning" on page 4</u>


Required tools and materials	Specification	Quantity
cleaner / degreaser	see <u>"Cleaning" on page 4</u>	as required
grease	Buzzy's Slick Honey	as required
Tool kit for dismounting the DU pin	CWTXX10031935S	1
Tool kit for dismounting the DU bushing	CWTXX10031927S	1
Tool kit for mounting the DU bushing	CXTXX10031928S	1

OVERVIEW




REMOVING THE SLEEVES

1. Remove the sleeves by hand.



TESTING THE DU BUSHINGS


- 1. Clamp the DU pin into a vice.
- 2. Rotate the shock on the pin to check the DU bushing.
 - → If the shock can be rotated without resistance, the DU Bushings must be changed. See following.
 - → If the shock can be rotated with resistance, the DU bushing must not be changed. Check the DU bushing again within the next small service. Mount the sleeves again (see <u>"Mounting the sleeves" on page 22</u>).





REMOVING THE DU PIN

- 1. Slide the pusher into the DU pin.
- 2. Align the receiver like shown in the picture.




3. Push out the DU pin using a press or a bench vise.

REMOVING THE DU-BUSHING

- 1. Slide the pusher into the DU bushing.
- 2. Align the receiver like shown in the picture.


3. Push out the DU bushing using a press or a

bench vise.




MOUNTING THE DU BUSHINGS


1. Slightly grease the inner surface of the shock eyelet and the outer surface of the bushing.



- 2. Put the bushing onto the pusher.
- 3. Position the bushing to the shock eyelet that the gap is oriented 90° to the axis of movement of the shock.
- 4. Align the receiver like shown in the picture.








MOUNTING THE DU PIN

1. Slightly grease the inner surface of the DU bushing and the outer surface of the DU pin.




- 2. Push in the DU pin by hand.
- 3. Position the pin centrally by clamping the pin in the vice and while turning the shock, pushing it to the center.
- Wait a few minutes and check the DU bushing again (see <u>"Testing the DU bushings" on page</u> <u>19</u>). If this test fails a second time, contact a DT Swiss

service center.

MOUNTING THE SLEEVES

- 1. Slightly grease the DU pin.
- 2. Slide the sleeves onto the DU pin.



Closing Steps	Link
Dispose all waste in an environmentally compatible manner.	<u>"1.6 Environmental protection" on page 4</u>
Assemble the shock to your bicycle.	


5. REPLACING SPHERICAL BEARINGS

DT Swiss shocks use DU bushings or spherical bearings. These two types, as well as their hardware and tools, are not compatible with each other.

Preparatory Steps	Link
Dismount the shock from the bike.	
Clean the surface of the shock.	see <u>"Cleaning" on page 4</u>

Required tools and materials	Specification	Quantity
cleaner / degreaser	see <u>"Cleaning" on page 4</u>	as required
thread locker	high-strength	as required
tool kit spherical bearings	CWTXX100289145	1

OVERVIEW





CHECKING THE SPHERICAL BEARINGS

- 1. Check the play of the spherical bearing by hand.
 - ightarrow If the spherical bearing can be moved without resistance, the spherical bearing should be replaced.


CHANGING THE SPHERICAL BEARINGS

- 1. Put the pin of the disassembly tool from one side into the spherical bearing.
- 2. Push the counter sleeve of the disassembly tool on the other side of the spherical bearing onto the pin of the disassembly tool.
- Press out the spherical bearing by compressing the disassembly tool. A vice, a hand press or the like can be used for pressing.
- Clean the eye of the shock with a degreaser and put a small amount of high-strength thread locker onto the inner surface of the shock's eye.





- 5. Position the spherical bearing in the shock eye so that the gap in the plastic ring is offset by 90° to the axis of motion of the shock.
- Press in the new spherical bearing using the assembly tool.
 A vice, a hand press or the like can be used for pressing in.
- 7. Take the tools and the shock out of the vice.
- 8. Remove excess threadlocker with a degreaser.



- 9. Check whether the spherical bearing is in the middle of the shock eye.
- 10. Check the spherical bearing again (see <u>"Checking the spherical bearings" on page 24</u>).

Closing Steps	Link
Dispose all waste in an environmentally compatible manner.	<u>"1.6 Environmental protection" on page 4</u>
Assemble the shock to your bicycle.	

DT SWISS AG Längfeldweg 101 CH - 2504 Biel/Bienne info.ch@dtswiss.com

DT SWISS, INC. 2493 Industrial Blvd. USA - Grand Junction, CO 81505 info.us@dtswiss.com

DT SWISS (FRANCE) S.A.S. Parc d'Activites de la Sarrée Route de Gourdon F - 06620 Le Bar sur Loup info.fr@dtswiss.com

DT SWISS ASIA LTD.

No.5, Jingke 5th Rd., Nantun District Taichung City 408 Taiwan (R.O.C.) info.tw@dtswiss.com

DT SWISS DEUTSCHLAND GmbH

Albert-Einstein-Strasse 3 59302 Oelde Germany info.de@dtswiss.com

DT SWISS POLSKA Sp. z o.o.

ul. Towarowa 36 PL-64-600 Oborniki Poland info.pl@dtswiss.com

Subject to technical alterations, errors and misprints excepted.

All rights reserved.

© by DT SWISS AG

www.dtswiss.com

CXD1000003031S